

A Technical Protocol for the Production and Extraction of Fermented Stevia Liquid

Part I: Foundational Knowledge - The Science of Fermented Stevia

1. Introduction: Unlocking Stevia's Bioactive Potential

***Stevia rebaudiana*: Beyond a Sweetener**

Stevia rebaudiana Bertoni, a perennial herb native to South America, is globally recognized for its leaves, which produce intensely sweet, non-caloric compounds.¹ These compounds, primarily steviol glycosides such as stevioside and rebaudioside A, are used extensively in the food and pharmaceutical industries as a sugar substitute.² However, a narrow focus on its sweetening properties overlooks the plant's rich and complex phytochemical profile. Stevia leaves are a reservoir of various bioactive compounds, including a diverse array of flavonoids and phenolic compounds such as chlorogenic acid, catechin, quercetin, and gallic acid.¹ These molecules are known to possess a range of biological activities, including antioxidant, anti-inflammatory, and antihypertensive effects.¹

Recent scientific inquiry has shifted the paradigm, viewing stevia not merely as an inert sweetener but as a source of chemical precursors that can be transformed into novel, pharmacologically active agents. The key to this transformation lies not in simple extraction

but in a sophisticated biotechnological process: microbial fermentation.

The Principle of Microbial Biotransformation

Microbial biotransformation has emerged as a powerful strategy to enhance the pharmacological efficacy of natural plant extracts.⁵ This process leverages the metabolic machinery of microorganisms, particularly their vast arsenal of enzymes, to structurally modify plant-derived compounds. Through reactions such as hydrolysis, acylation, and dehydrogenation, microbial enzymes can convert parent compounds into secondary metabolites, which often exhibit improved bioactivity or bioavailability compared to their original forms.⁵

Lactic Acid Bacteria (LAB), a group of microorganisms with "Generally Recognized As Safe" (GRAS) status, are frequently employed for this purpose.⁵ Fermentation with specific LAB strains has been shown to enhance the anticancer potential of various plant materials. For instance, barley extract fermented with

Lactobacillus plantarum demonstrated a stronger inhibitory effect on colon cancer cells, and the fermentation of *Panax notoginseng* with LAB increased its antiproliferative activity against liver cancer cells by enriching for specific bioactive ginsenosides.⁵ This principle is central to the protocol detailed herein; the fermentation of stevia is not a culinary exercise for flavor development but a targeted biochemical synthesis designed to convert a naturally occurring precursor in the stevia leaf into a potent new molecule.⁷

2. The Hiroshima University Breakthrough: From Plant Extract to Potent Metabolite

Summary of the Core Research

Researchers at Hiroshima University have pioneered a novel application of this principle, detailed in the *International Journal of Molecular Sciences*.³ Their work investigated the effects of fermenting an aqueous extract of stevia leaves with a specific bacterial strain. The central finding of their study was that the resulting Fermented Stevia Leaf Extract (FSLE)

demonstrated significantly greater cytotoxicity against a line of human pancreatic cancer cells (PANC-1) in laboratory tests compared to the non-fermented stevia extract at equivalent concentrations.⁸ Crucially, this potent effect was highly selective; the FSLE showed minimal toxicity toward healthy, non-cancerous human embryonic kidney cells (HEK-293), even at the highest concentrations tested.⁹ This discovery suggests that the fermentation process unlocks or creates compounds with targeted anti-cancer activity.

It is of paramount importance to contextualize these findings. The research was conducted *in vitro*, meaning "in glass," referring to experiments performed on isolated cells in a controlled laboratory environment such as a petri dish or test tube. These results are preliminary and represent an early stage of scientific discovery.³ A massive biological and regulatory gap exists between a successful

in vitro experiment and a proven, safe, and effective therapy for use in humans. Therefore, the product of this protocol must be considered a substance for research and experimental purposes only and not a medical treatment or "cure."

The Active Compound: Chlorogenic Acid Methyl Ester (CAME)

Through detailed chemical analysis, the Hiroshima University team identified the primary bioactive metabolite responsible for the observed anticancer effects as Chlorogenic Acid Methyl Ester (CAME).¹ The study revealed that during fermentation, the concentration of chlorogenic acid, a natural constituent of stevia leaves, dropped six-fold, indicating its microbial transformation into the more potent CAME.⁸ The final concentration of CAME achieved in the laboratory fermentation broth was 374.4 µg/mL, a benchmark that provides context for the potency observed in the study, though it is not a metric that can be measured in a non-laboratory setting.¹

The mechanism of action for CAME was further elucidated, revealing a multi-pronged attack on the cancer cells. CAME was found to arrest the cancer cell cycle in the G0/G1 phase, effectively halting their proliferation.¹ Furthermore, it induces apoptosis, or programmed cell death, a natural process where damaged cells self-destruct.⁷ This is achieved by altering the genetic programming of the cancer cells. CAME upregulates the expression of pro-apoptotic genes (such as

Bax, *Bad*, and *Caspase-3/9*) while simultaneously downregulating the expression of anti-apoptotic genes (like *Bcl-2*), creating a powerful "double hit" that encourages the malignant cells to eliminate themselves.¹

Enhanced Antioxidant Properties

A secondary but significant finding of the research was that the fermentation process also substantially enhanced the antioxidant capacity of the stevia extract.¹ Oxidative stress, which is an imbalance of harmful free radicals in the body, is closely linked to the development of cancer and other chronic diseases. The increased antioxidant activity of the FSLE, as measured by DPPH and ABTS radical scavenging assays, represents an additional health-promoting property generated by the biotransformation process.¹

3. The Key Agent: A Profile of *Lactobacillus plantarum*

General Characteristics

Lactobacillus plantarum (recently reclassified as *Lactiplantibacillus plantarum*) is a highly versatile, gram-positive Lactic Acid Bacterium (LAB).¹² It is widespread in nature and commonly found in many fermented plant-based foods, including sauerkraut, pickles, kimchi, and sourdough.¹⁴ It is also a natural and beneficial inhabitant of the human gastrointestinal tract, where it contributes to gut health.¹³ Due to its long history of safe use in food production and its probiotic properties,

L. plantarum holds "Generally Recognized As Safe" (GRAS) status, making it an ideal candidate for food-related biotechnological applications.⁵

The Specific Strain: SN13T

The success of the Hiroshima University research is critically dependent on the specific bacterial strain used: *L. plantarum* SN13T.⁷ This particular strain was isolated by the research team from banana leaves, highlighting the rich microbial diversity found on plant surfaces.¹⁰ Prior to its use in stevia fermentation, strain SN13T had already been identified as a promising probiotic. Previous human trials demonstrated its ability to improve constipation and liver

function, as evidenced by a significant reduction in serum γ -glutamyl transpeptidase (γ -GTP) levels.¹⁸ Its robustness is notable, showing greater resistance to artificial gastric juices and bile than many animal-derived LAB strains, a key trait for a successful probiotic.¹⁸

The Enzymatic Engine: β -glucosidase

The biotransformation of compounds within the stevia leaf extract is not a random occurrence but a direct result of the enzymatic machinery harbored by *L. plantarum* SN13T.¹⁸ The key enzymes implicated in this type of reaction are β -glucosidases.¹⁹ These enzymes specialize in hydrolyzing (breaking) β -glycosidic bonds, which link sugar molecules (glycones) to other molecules (aglycones).²¹ In plants, many bioactive compounds, such as flavonoids and phenolics, exist in a glycosylated state. This sugar attachment often renders them less biologically active or bioavailable.²²

The action of β -glucosidase cleaves this bond, releasing the bioactive aglycone. This enzymatic activity is the engine of biotransformation, converting less active precursors into potent metabolites.²⁰ The specific capabilities of strain SN13T have been demonstrated in other contexts; for example, when used to ferment an extract of gardenia fructus, its β -glucosidase enzymes efficiently convert the iridoid glycoside geniposide into its more bioactive aglycone, genipin.¹⁸ This provides a strong parallel mechanism for the conversion of chlorogenic acid and other stevia compounds into CAME and other novel metabolites.

The entire premise of this protocol hinges on harnessing this specific enzymatic activity. The research strain *L. plantarum* SN13T is proprietary and not commercially available. Therefore, the selection of a suitable, publicly available substitute strain of *L. plantarum* is the single most critical variable and the greatest potential point of failure in replicating the research findings. Different strains of *L. plantarum* possess different types and levels of β -glucosidase activity, which will directly impact the chemical composition and potential bioactivity of the final fermented product.²⁰ The goal is not simply to grow any

Lactobacillus in a stevia tea, but to select a strain with a high likelihood of possessing the enzymatic tools necessary to perform the desired chemical conversion.

4. Critical Safety and Ethical Considerations

Disclaimer: For Research Purposes Only

This protocol is provided for educational, experimental, and research purposes only. The resulting fermented liquid is an experimental substance whose chemical composition, safety, and efficacy have not been verified outside of a controlled laboratory setting. The *in vitro* findings regarding anticancer activity are preliminary and cannot be extrapolated to human health.³

This product is not a proven medical treatment, has not been tested for human safety, and must not be consumed or used for self-medication under any circumstances. Any application to human health would require extensive clinical trials and regulatory approval.

The Imperative of Aseptic Technique

The successful execution of this protocol is absolutely dependent on the consistent application of aseptic (sterile) technique. The objective is to create a monoculture, where only the desired *L. plantarum* strain is allowed to grow and ferment the stevia extract. Failure to maintain a sterile environment at all stages will inevitably lead to contamination by unwanted microorganisms from the air, surfaces, or non-sterile equipment. These contaminants, which can include other bacteria, molds, and yeasts, will compete with the *L. plantarum* for nutrients, spoil the fermentation, and potentially produce unknown or harmful compounds. Adherence to the sterilization procedures outlined in this protocol is a non-negotiable prerequisite for both the success and safety of the experiment.

Biosafety Level 1 (BSL-1)

Lactobacillus plantarum is classified as a Biosafety Level 1 (BSL-1) organism.²⁵ This is the lowest biosafety level and is applied to agents that are not known to consistently cause disease in healthy human adults and present a minimal potential hazard to laboratory personnel and the environment. Despite this low-risk classification, standard microbiological practices should always be followed. This includes wearing personal protective equipment (gloves, safety glasses), washing hands thoroughly before and after handling cultures, decontaminating work surfaces, and properly disposing of all used cultures and materials.

Part II: The Protocol - A Practical Guide to Creating Fermented Stevia Liquid

5. Essential Equipment and Materials

A comprehensive list of required equipment and materials is provided below. Success depends on having the proper tools to maintain sterility and control the fermentation parameters. The list is categorized by function.

Category	Item	Quantity	Purpose	Notes / Alternatives
Main Fermentation	1.5-Gallon Glass Carboy or Jar	1	Primary anaerobic fermentation vessel for the 1-gallon batch.	A food-grade plastic bucket with a gasketed lid can be used, but glass is preferred for its non-reactivity, ease of cleaning, and visibility.
	Drilled Stopper or Lid	1	To seal the fermentation vessel and hold the airlock.	Must be sized to fit the carboy/jar opening.
	3-Piece or S-Type	1	Allows fermentation-produced	An essential component for

	Airlock		CO ₂ to escape while preventing oxygen and contaminants from entering.	maintaining anaerobic conditions.
	Large Stock Pot (≥ 2 Gallons)	1	For preparing and heating the stevia leaf extract.	Stainless steel or enamel is recommended. Avoid aluminum.
	Digital pH Meter or pH Strips	1	To monitor the progress of fermentation by measuring the drop in pH.	A calibrated digital meter is highly recommended for accuracy. pH strips (range 2-7) are a less precise alternative.
	Heating Mat or Incubation Chamber	1	To maintain the optimal fermentation temperature of 37°C (98.6°F).	A seedling germination mat with a temperature controller is ideal. A small, enclosed space (e.g., a cabinet) with a low-wattage heat source can also work but requires careful

				monitoring.
	Auto-Siphon or Tubing	1	For aseptically transferring liquids, especially during harvesting.	Essential for separating the fermented liquid from the bacterial sediment.
Starter Culture	500 mL Erlenmeyer Flask or Mason Jar	1	Vessel for preparing and incubating the starter culture.	Must be able to withstand sterilization in a pressure cooker.
	Aluminum Foil or Foam Stopper	1	To cover the starter flask during sterilization and incubation.	
Sterilization & Handling	Pressure Cooker or Canner (≥ 10-Quart)	1	To sterilize the growth medium, stevia extract, and equipment.	This is the most critical piece of equipment for ensuring sterility. An autoclave is the laboratory standard.
	Digital Scale (0.1g precision)	1	For accurately weighing stevia leaves, medium components,	

			etc.	
	Graduated Cylinders / Measuring Cups	Set	For measuring liquid volumes.	
	Star San or Iodophor Sanitizer	1 Bottle	No-rinse sanitizer for surfaces and equipment that cannot be pressure-coo ked.	Follow manufacturer 's instructions for proper dilution and contact time.
	Isopropyl Alcohol (70%)	1 Bottle	For sanitizing surfaces, gloves, and equipment exteriors.	
	Sterile Syringes and Filters (0.22 μm)	Optional	For sterile-filterin g the final product for maximum purity.	The research paper specifies a 0.22 μm filter. ⁵ This provides the highest level of clarification.
	Glass Bottles with Airtight Lids	Several	For storing the final product.	

6. Sourcing and Preparing Your Ingredients

The quality and specificity of the starting materials, particularly the bacterial culture, will dictate the outcome of the fermentation.

Stevia Leaf Selection

It is essential to use high-quality, organic, dried stevia leaves. The leaves contain the full spectrum of phytochemicals, including the chlorogenic acid that serves as the precursor to CAME.¹ Avoid using processed white stevia powders, liquid extracts, or sweetener blends (e.g., Truvia, Pure Via). These products consist of isolated steviol glycosides and have had the other necessary plant compounds removed during processing.² The research paper mentions using dried stevia leaves from Kojima Kampo Co., Ltd., which serves as a quality reference.⁵

The Critical Choice: Sourcing a Lactobacillus plantarum Culture

As the specific SN13T strain is unavailable, a substitute must be carefully chosen. The goal is to find a strain known for robust activity on plant-based substrates, which implies strong enzymatic capabilities.

Ingredient	Specification	Sourcing Options	Pros	Cons
Dried Stevia Leaves	Organic, whole or cut leaf	Health food stores, online herbal suppliers, specialty tea shops.	Ensures the presence of the full range of necessary phytochemicals.	Must be free of additives or other herbs.
L. plantarum Culture	High-purity, single strain	1. Culture Banks: ATCC (e.g., 14917, 8014), DSMZ. ²⁶	Genetically defined, highest purity, well-characterized	Expensive, may require institutional affiliation to purchase, requires

			rized.	handling of lyophilized pellets.
		2. Brewing Suppliers: White Labs (WLP693), Escarpment Labs, Lallemend (Sour Pitch). ²⁹	High viability, designed for fermentation, readily available to the public.	Strain is selected for beer souring, not necessarily for specific biotransformation.
		3. Probiotic Retailers: Bulk powders or high-CFU, single-strain capsules. ¹⁴	Highly accessible, relatively inexpensive.	Strain identity may be less defined, may contain fillers, viability can vary. Must be a single-strain product.
Bacterial Growth Medium	Nutrient-rich broth	1. Laboratory Suppliers: Dehydrated MRS Broth powder. ³⁴	The exact medium used in the research, optimized for lactobacilli growth. ⁵	Can be difficult to source for individuals, may be expensive.
		2. DIY / Homebrew Shops: Dry Malt Extract (DME), Yeast Nutrient, Dextrose, Calcium Carbonate. ³⁶	Components are readily available and inexpensive.	Not identical to MRS, but provides the necessary carbohydrates, nitrogen, and minerals for good growth. ³⁷

Bacterial Growth Medium (Nutrients)

The research protocol utilized de Man, Rogosa, and Sharpe (MRS) broth, the gold standard for cultivating lactobacilli.⁵ If available, this is the preferred option.

- **To Prepare MRS Broth:** Follow the manufacturer's instructions, typically suspending 55 grams of powder per 1 liter of distilled water.³⁴

If MRS broth is not accessible, a DIY starter medium can be formulated to meet the nutritional requirements of *L. plantarum*. Lactobacilli require a source of carbohydrates (sugars), nitrogen (amino acids, peptides), and key minerals for robust growth.³⁷

- **DIY Lactobacillus Starter Medium Recipe (per 400 mL):**
 - Distilled Water: 400 mL
 - Light Dry Malt Extract (DME): 36 g
 - Dextrose (Corn Sugar): 8 g
 - Yeast Nutrient or Diammonium Phosphate (DAP): 0.4 g
 - Calcium Carbonate (CaCO₃ / Chalk): 8 g (optional, acts as a buffer to prevent pH from dropping too low and inhibiting growth).³⁶

7. Phase 1: Activation and Cultivation of the Starter Culture

The objective of this phase is to create a small (~400 mL) but highly active and concentrated liquid culture of *L. plantarum*. This "starter" ensures a rapid and healthy start to the main fermentation, outcompeting any potential trace contaminants. This process directly mirrors the "Bacterial Cultivation" step from the research methodology.⁵

1. **Prepare the Starter Medium:**
 - Combine the components for 400 mL of either MRS Broth or the DIY Starter Medium in a 500 mL Erlenmeyer flask or mason jar.
 - Mix until all powders are dissolved. The solution will be cloudy.
 - Cover the mouth of the flask/jar loosely with aluminum foil. This prevents contaminants from entering while allowing pressure to escape during sterilization.
2. **Sterilize the Medium:**
 - Place the flask/jar into a pressure cooker on a rack, ensuring it is not in direct contact with the bottom. Add water to the pressure cooker as per the manufacturer's instructions.
 - Sterilize at 15 PSI (121°C) for 15 minutes.

- Allow the pressure cooker to cool and depressurize completely on its own before opening. This prevents the liquid medium from boiling over.
- 3. **Cool and Inoculate:**
 - Let the sterilized medium cool to the target incubation temperature of 37°C (98.6°F). This is critically important; temperatures above 43°C (110°F) can kill the bacteria.
 - In a clean environment with minimal air movement, perform the inoculation. If using a lyophilized pellet from a culture bank, rehydrate it in a small amount of the sterile broth before adding the entire contents to the flask. If using probiotic powder, aseptically open one or two capsules and empty the contents directly into the medium. If using a liquid culture from a brewing supplier, sanitize the exterior of the package and pour the contents in.
 - Swirl the flask gently to mix.
- 4. **Incubate the Starter:**
 - Place the inoculated flask on the heating mat or in the incubator set to 37°C.
 - Incubate for 24 to 48 hours.⁵
 - Successful activation will be indicated by a noticeable increase in turbidity (cloudiness) as the bacterial population grows. The aroma should be clean and slightly sour. This active culture is now ready to be used to inoculate the main batch.

8. Phase 2: Preparation of the Stevia Fermentation Medium (SLE)

This phase involves creating one gallon of sterile 5% (w/v) Stevia Leaf Extract (SLE), which will serve as the substrate for fermentation. This protocol scales up the method described in the research paper.⁵

- **Recipe for ~1 Gallon (3785 mL) of 5% SLE:**
 - Dried Stevia Leaves: 190 g (rounded from 189.25 g)
 - Distilled Water: 4000 mL (1.06 gallons) to account for absorption by leaves and evaporative loss.
- 1. **Extraction:**
 - Combine the 190 g of dried stevia leaves and 4000 mL of distilled water in the large stockpot.
 - Bring the mixture to a boil. The research specifies heating at 105°C for 30 minutes, which is difficult to achieve without pressurized equipment. A practical equivalent is to maintain a gentle, rolling boil for 30 minutes with the lid slightly ajar.⁵
- 2. **Solid Removal:**
 - Allow the extract to cool enough to be handled safely.
 - Strain the liquid through several layers of cheesecloth or a fine-mesh sieve into a sanitized temporary container. Squeeze the leaves to recover as much liquid as possible.

3. Sterilization:

- Transfer the strained stevia leaf extract into the 1.5-gallon glass fermentation vessel.
- This step presents a challenge for home setups due to the large volume. If the vessel fits in a large pressure canner, place it inside and sterilize at 15 PSI for 20-25 minutes.
- If the vessel is too large, the liquid must be sterilized in the stockpot (15 PSI for 30 minutes) and then aseptically transferred to the pre-sanitized fermentation vessel. This carries a higher risk of contamination and must be done quickly and carefully.

4. Cooling:

- Whether sterilized in-place or transferred, the SLE must be cooled completely to the target inoculation temperature of 37°C (98.6°F). This can take several hours. A sanitized thermometer can be used to check the temperature.

9. Phase 3: The Fermentation Process

This is the core phase where the active *L. plantarum* culture is introduced to the sterile stevia medium to begin the biotransformation process. The parameters are based directly on the optimized conditions from the Hiroshima University study.⁵

Parameter	Value	Rationale / Source
Total Volume	~1 Gallon (3785 mL)	User-specified target volume.
Substrate	5% (w/v) Sterile Stevia Leaf Extract (SLE)	The concentration used in the original research. ⁵
Inoculum Volume	~400 mL Active Starter Culture	Provides a high density of viable cells for a rapid start.
Fermentation Temperature	37°C (98.6°F)	Optimal temperature for producing bioactive compounds, superior to 28°C. ⁵
Duration	72 hours	Research tested 24, 48,

		and 72 hours; 72 hours provides maximum time for bioconversion. ⁵
Environment	Anaerobic (Airlocked)	Prevents oxygen exposure and contamination, as used in the research. ⁵

1. **Inoculation:**
 - Working in a sanitized area, carefully remove the foil from the starter culture flask and the cover from the main fermentation vessel.
 - Pour the entire 400 mL active starter culture into the cooled, sterile stevia medium. Swirl gently to mix.
2. **Seal for Anaerobic Conditions:**
 - Immediately place the sanitized, drilled stopper into the mouth of the carboy.
 - Insert the sanitized airlock into the stopper. Fill the airlock to the indicated line with sanitizer solution or vodka.
3. **Incubate:**
 - Place the sealed fermentation vessel in the pre-heated incubator or on the heating mat set to 37°C.
 - Ensure the temperature probe (if using a controller) is attached to the side of the carboy and insulated to get an accurate reading of the liquid's temperature.
4. **Maintain and Observe:**
 - Maintain the temperature at a constant 37°C for the full 72-hour duration.
 - Check the airlock periodically. While vigorous bubbling is not expected, some initial activity may be visible as the culture acclimates and produces small amounts of CO₂.

10. Monitoring Fermentation Milestones

Without access to advanced analytical equipment like High-Performance Liquid Chromatography (HPLC) to measure CAME concentration, progress must be monitored using accessible indicators.

- **Visual Cues:** The liquid will appear cloudy due to the suspended bacterial cells. Over the 72 hours, there may be some formation of sediment (lees) at the bottom of the vessel as older cells settle out. No mold, strange films, or "ropy" strands should be visible; these are definitive signs of contamination.
- **Aroma:** The aroma should be clean, mildly acidic, and reminiscent of a sour tea. Any off-aromas, particularly those that are putrid, cheesy (in a bad way), solvent-like (e.g.,

nail polish remover), or moldy, indicate a failed fermentation due to contamination. The batch must be discarded if these are detected.

- **pH Monitoring (Critical Indicator):** This is the most valuable and accessible metric for tracking the fermentation. *Lactobacillus* species produce lactic acid as a primary metabolic byproduct, which will cause the pH of the medium to drop.
 - **Baseline:** Before inoculation, the sterile SLE should have a pH near neutral (likely between 6.0 and 7.0).
 - **Progression:** A successful fermentation will show a steady decrease in pH over the 72-hour period.
 - **Target:** A final pH in the range of 3.5 to 4.5 is a strong indicator of healthy and active *Lactobacillus* fermentation. A failure for the pH to drop below 5.0 suggests the fermentation has stalled or failed.

Part III: Harvesting, Post-Processing, and Further Exploration

11. The "Extraction" Process: Harvesting the Bioactive Liquid

In the context of the research paper and this protocol, "extraction" refers to the mechanical separation of the liquid supernatant from the solid bacterial biomass.⁵ The goal is to obtain a clarified liquid containing the dissolved bioactive compounds, including any CAME that was produced.

Method 1 (Good): Cold Crashing and Siphoning

This method is a low-technology adaptation of laboratory centrifugation and is effective for clarification.

1. **Cold Crashing:** Once the 72-hour fermentation is complete, carefully move the entire fermentation vessel into a refrigerator (set to ~4°C or 40°F). Let it sit undisturbed for 24 to 48 hours. The cold temperature will encourage the suspended bacterial cells to flocculate (clump together) and settle to the bottom, forming a compact sediment layer.
2. **Siphoning:** Place the fermentation vessel on a counter or table. Place a sanitized

collection container (e.g., another carboy or large jar) on the floor below it. Start a siphon using the auto-siphon or tubing, ensuring the intake end is positioned well above the sediment layer. Carefully transfer the clear liquid, leaving the bacterial sediment behind. Stop siphoning before the sediment is disturbed.

Method 2 (Better): Sterile Filtration

For a final product that is free of all bacterial cells and particulates, mirroring the "sterile FSLE" from the research, filtration is required.⁵

1. **Prepare Equipment:** Aseptically assemble a large sterile syringe (e.g., 60 mL) and a sterile-packaged syringe filter with a pore size of 0.22 μm or 0.45 μm . The 0.22 μm filter will provide a sterile filtrate.
2. **Filter:** Siphon the fermented liquid into a sanitized intermediate container first. Then, draw the liquid into the syringe, attach the filter, and slowly press the plunger to force the liquid through the filter into the final, sterile storage bottles. This process can be slow and may require multiple filters as they can clog.

12. Final Product: Storage and Stability

- **Bottling:** The final filtered liquid should be stored in sterile glass bottles or jars with airtight, corrosion-resistant lids (plastic or lined metal).
- **Preservation:** The final product must be stored under refrigeration at all times ($\sim 4^{\circ}\text{C}$ or 40°F). The low pH of the liquid provides a degree of microbial stability, but refrigeration is essential to preserve the chemical integrity of the dissolved compounds and prevent the growth of any potential acid-tolerant spoilage organisms. The potential shelf life under these conditions is estimated to be several months, but this is not guaranteed. The liquid should be periodically inspected for any changes in clarity, color, or aroma before any further experimental use.

13. Troubleshooting and Avenues for Experimentation

Troubleshooting Guide

Problem	Possible Causes	Solutions
No activity: No pH drop, no change in clarity after 24-48 hours.	1. Inactive/dead starter culture (old probiotic, poor shipping/storage). 2. Incorrect incubation temperature (too hot or too cold). 3. Residual sanitizer in equipment.	1. Source a fresh, high-viability culture. Always make a starter to confirm activity before pitching. 2. Calibrate and verify the temperature of the incubation setup. 3. Ensure all equipment is thoroughly rinsed if using a rinse-required sanitizer. Use a no-rinse sanitizer like Star San.
Mold growth or foul odors: Visible mold on the surface; aromas are putrid, solvent-like, or otherwise unpleasant.	Contamination from a break in aseptic technique during preparation, sterilization, or inoculation.	Discard the entire batch safely. Add bleach to the vessel, let it sit for several hours, and then dispose of the liquid. Thoroughly clean and re-sanitize all equipment. Review every step of the aseptic procedure to identify and correct the error.
Fermentation stalls: pH drops initially but then stops high (e.g., >4.8).	1. Insufficient nutrients in the starter or main medium. 2. The selected bacterial strain is not robust enough. 3. The pH has dropped to the strain's tolerance limit.	1. Ensure the starter medium is nutrient-rich (use MRS or a fortified DIY version). 2. Try a different source or strain of <i>L. plantarum</i> . 3. This may be the limit for the chosen strain; consider this the final product for that experiment.

Avenues for Further Experimentation

For the dedicated citizen scientist, this protocol serves as a baseline for further inquiry. All experiments should be conducted on a smaller scale (e.g., 500 mL jars) to conserve materials.

- **Strain Comparison:** The most impactful variable to test is the bacterial strain. Conduct parallel small-batch fermentations using different commercially available *L. plantarum* strains (e.g., ATCC 14917 vs. a brewing strain vs. a probiotic strain). Monitor and compare the rate and final value of the pH drop for each.
- **Parameter Optimization:** Vary single parameters while keeping all others constant. For example, compare fermentation durations (48 vs. 72 vs. 96 hours) or temperatures (35°C vs. 37°C vs. 39°C) to map their effects on the final pH.
- **Substrate Variation:** Experiment with the concentration of the stevia leaf extract. Compare the standard 5% (w/v) against a lower 3% and a higher 7% concentration to observe any impact on the fermentation speed and final acidity.

Conclusion

This protocol provides a comprehensive, scientifically-grounded framework for the experimental production of fermented stevia liquid, based on the pioneering research from Hiroshima University. It translates a laboratory-scale process into a feasible one-gallon batch for a non-commercial, experimental setting. The procedure highlights a paradigm shift in the perception of *Stevia rebaudiana*, treating it not as a simple sweetener but as a source of valuable phytochemical precursors. The core of the process is microbial biotransformation, driven by the enzymatic activity of *Lactobacillus plantarum*, to theoretically produce the bioactive compound Chlorogenic Acid Methyl Ester (CAME).

Success is contingent upon three critical factors: the meticulous application of aseptic technique to prevent contamination, the precise control of fermentation parameters (especially temperature), and the careful selection of a viable and enzymatically active substitute for the unavailable *L. plantarum* SN13T research strain. The final pH of the liquid serves as the most reliable and accessible indicator of successful lactic acid fermentation.

It must be unequivocally understood that this is an advanced scientific experiment. The resulting product is intended solely for research and analytical exploration. The preliminary *in vitro* anti-cancer findings that motivate this protocol are not a basis for human consumption or self-medication. By approaching this project with scientific rigor, careful documentation,

and a paramount focus on safety, the citizen scientist can explore the fascinating intersection of botany, microbiology, and biotechnology.

Works cited

1. (PDF) Stevia Leaf Extract Fermented with Plant-Derived *Lactobacillus plantarum* SN13T Displays Anticancer Activity to Pancreatic Cancer PANC-1 Cell Line - ResearchGate, accessed August 17, 2025, https://www.researchgate.net/publication/391273297_Stevia_Leaf_Extract_Fermented_with_Plant-Derived_Lactobacillus_plantarum_SN13T_Displays_Anticancer_Activity_to_Pancreatic_Cancer_PANC-1_Cell_Line
2. US10815513B2 - Fermentation methods for producing steviol glycosides using high pH and compositions obtained therefrom - Google Patents, accessed August 17, 2025, <https://patents.google.com/patent/US10815513B2/en>
3. Fermented Stevia extract as cure for pancreatic cancer possible, Japanese scientists make a breakthrough using sugar substitute - The Economic Times, accessed August 17, 2025, <https://m.economictimes.com/news/international/us/fermented-stevia-extract-as-cure-for-pancreatic-cancer-possible-japanese-scientists-make-a-breakthrough-using-sugar-substitute/articleshow/123157930.cms>
4. Bioactive compounds identified in stevia (*Stevia rebaudiana*) - ResearchGate, accessed August 17, 2025, https://www.researchgate.net/figure/Bioactive-compounds-identified-in-stevia-Stevia-rebaudiana_fig1_358966564
5. Stevia Leaf Extract Fermented with Plant-Derived *Lactobacillus* ..., accessed August 17, 2025, <https://pmc.ncbi.nlm.nih.gov/articles/PMC12071683/>
6. This sugar substitute does more than sweeten — it kills cancer cells - ScienceDaily, accessed August 17, 2025, <https://www.sciencedaily.com/releases/2025/07/250722044704.htm>
7. The tea sweetener that could become a natural, cost-effective cancer therapy, accessed August 17, 2025, <https://www.independent.co.uk/life-style/health-and-families/pancreatic-cancer-symptoms-fermented-stevia-sweetener-b2797305.html>
8. Stevia leaf extract has potential as anticancer treatment, researchers find - EurekAlert!, accessed August 17, 2025, <https://www.eurekalert.org/news-releases/1091699>
9. Stevia leaf extract has potential as anticancer treatment, researchers find | Hiroshima University, accessed August 17, 2025, <https://www.hiroshima-u.ac.jp/en/news/91640>
10. Stevia leaf extract has potential as anticancer treatment, researchers find - eCancer, accessed August 17, 2025, <https://ecancer.org/en/news/26775-stevia-leaf-extract-has-potential-as-anticancer-treatment-researchers-find>
11. Stevia Leaf Extract Fermented with Plant-Derived *Lactobacillus plantarum* SN13T Displays Anticancer Activity to Pancreatic Cancer PANC-1 Cell Line - PubMed,

- accessed August 17, 2025, <https://pubmed.ncbi.nlm.nih.gov/40362423/>
12. Species: Lactiplantibacillus plantarum - LPSN, accessed August 17, 2025, <https://lpsn.dsmz.de/species/lactiplantibacillus-plantarum>
 13. The Impacts of Lactiplantibacillus plantarum on the Functional Properties of Fermented Foods: A Review of Current Knowledge - MDPI, accessed August 17, 2025, <https://www.mdpi.com/2076-2607/10/4/826>
 14. Lactobacillus Plantarum Probiotic Powder – BP, accessed August 17, 2025, <https://bulkprobiotics.com/products/lactobacillus-plantarum-probiotic-powder>
 15. Lactobacillus - Milk The Funk Wiki, accessed August 17, 2025, <https://www.milkthefunk.com/wiki/Lactobacillus>
 16. Rethinking stevia: The sweet leaf that may fight cancer - Earth.com, accessed August 17, 2025, <https://www.earth.com/news/rethinking-stevia-the-sweet-leaf-that-may-fight-cancer/>
 17. Scientists Supercharge Sugar Substitute – And It Starts Killing Cancer - SciTechDaily, accessed August 17, 2025, <https://scitechdaily.com/scientists-supercharge-sugar-substitute-and-it-starts-killing-cancer/>
 18. Transcriptional profiling of geniposide bioconversion into genipin during gardenia fructus extract fermentation by Lactobacillus (Lactiplantibacillus) plantarum SN13T - PMC, accessed August 17, 2025, <https://pmc.ncbi.nlm.nih.gov/articles/PMC10981940/>
 19. Enhanced β -Glucosidase Activity of *Lactobacillus plantarum* by a Strategic Ultrasound Treatment for Biotransformation of Isoflavones in Okara - J-Stage, accessed August 17, 2025, https://www.jstage.jst.go.jp/article/fstr/24/5/24_777/_html/-char/en
 20. β -Glucosidase Activity of Lactiplantibacillus plantarum: A Key Player in Food Fermentation and Human Health | Scilit, accessed August 17, 2025, <https://www.scilit.com/publications/e43033c932f1499e8135155efc13f4e4>
 21. (PDF) β -Glucosidase Activity of Lactiplantibacillus plantarum: A Key Player in Food Fermentation and Human Health - ResearchGate, accessed August 17, 2025, https://www.researchgate.net/publication/391026080_b-Glucosidase_Activity_of_Lactiplantibacillus_plantarum_A_Key_Player_in_Food_Fermentation_and_Human_Health
 22. β -Glucosidase activities of lactic acid bacteria: mechanisms, impact on fermented food and human health | FEMS Microbiology Letters | Oxford Academic, accessed August 17, 2025, <https://academic.oup.com/femsle/article/352/1/1/553432>
 23. β -Glucosidase Activity of Lactiplantibacillus plantarum: A Key Player in Food Fermentation and Human Health - MDPI, accessed August 17, 2025, <https://www.mdpi.com/2304-8158/14/9/1451>
 24. β -Glucosidase Activity of Lactiplantibacillus plantarum UNQLp 11 in Different Malolactic Fermentations Conditions: Effect of pH and Ethanol Content - MDPI, accessed August 17, 2025, <https://www.mdpi.com/2311-5637/7/1/22>

25. Microbiologics Lactobacillus plantarum ATCC 8014 Kwik-stik™ | Buy Online, accessed August 17, 2025, <https://www.fishersci.com/shop/products/microbiologics-i-lactobacillus-plantarum-i-atcc-8014-2/23003209>
26. Lactiplantibacillus plantarum (Orla-Jensen) Zheng et al. - 14917 | ATCC, accessed August 17, 2025, <https://www.atcc.org/products/14917>
27. Lactiplantibacillus plantarum (Orla-Jensen) Zheng et al. - 8014 | ATCC, accessed August 17, 2025, <https://www.atcc.org/products/8014>
28. Lactiplantibacillus plantarum subsp. plantarum - Leibniz Institute DSMZ, accessed August 17, 2025, <https://www.dsmz.de/collection/catalogue/details/culture/DSM-2648>
29. Lactobacillus Plantarum - Escarpment Labs, accessed August 17, 2025, <https://escarpmentlabs.com/products/lactobacillus-plantarum>
30. WLP693 Lactobacillus plantarum - White Labs, accessed August 17, 2025, <https://www.whitelabs.com/yeast-single?id=199&type=YEAST>
31. WildBrew™ Sour Pitch Lactobacillus Plantarum - 10 grams - Northern Brewer, accessed August 17, 2025, <https://www.northernbrewer.com/products/lallem-and-wildbrew-sour-pitch-10-grams>
32. Probiotic blend of Lactobacillus plantarum 20 Billion CFU/GRAM High Quality 21 | eBay, accessed August 17, 2025, <https://www.ebay.com/itm/323318364164>
33. Swanson L. Plantarum - Digestive Supplement Promoting Gastrointestinal Balance & Bowel Regularity - Natural Formula to Help Reduce Bloating - (30 Veggie Capsules) - Walmart, accessed August 17, 2025, <https://www.walmart.com/ip/Swanson-Lactobacillus-Plantarum-Probiotic-Inner-Bowel-Support-Vegetable-Capsules-10-Billion-Cfu-30-Count/198704740>
34. Lactobacilli MRS Agar - Manual Difco, accessed August 17, 2025, <https://cdn.media.interlabdist.com.br/uploads/2021/01/Lactobacilli-MRS-Agar-e-Broth.pdf>
35. CRITERION™ Lactobacilli MRS Broth, Dehydrated Culture Media, 10kg Bucket, accessed August 17, 2025, <https://hardydiagnostics.com/c5933>
36. Lactobacillus 2.0 - Advanced Techniques for Fast Souring Beer, accessed August 17, 2025, <https://www.sourbeerblog.com/lactobacillus-2-0-advanced-techniques-for-fast-souring-beer/>
37. Determination of the essential nutrients required for milk fermentation by Lactobacillus plantarum | Request PDF - ResearchGate, accessed August 17, 2025, https://www.researchgate.net/publication/283907539_Determination_of_the_essential_nutrients_required_for_milk_fermentation_by_Lactobacillus_plantarum
38. Yeast Creates a Niche for Symbiotic Lactic Acid Bacteria through Nitrogen Overflow - PMC, accessed August 17, 2025, <https://pmc.ncbi.nlm.nih.gov/articles/PMC5660601/>
39. Yeast-based Nutrients Selection: a Key Choice to Improve Your Probiotics Production, accessed August 17, 2025,

<https://procelys.com/yeast-based-nutrients-selection-a-key-choice-to-improve-your-probiotics-production/>